



### Difference between Cosmo och Cosmo Plus



**Model Cosmo (without bar)**  
Start: Foot switch.  
Stop: Shuts off with timer  
(approx 1 min.)



**Model Cosmo Plus (with bar)**  
Start: Touch switch on bar.  
Stop: Stops when hand is  
taken off the bar.

### Colour options for Cosmo and Cosmo Plus

Both Cosmo and Cosmo Plus are available in the colours below.



Colour: Black (RAL 9005)  
Models: Cosmo and Cosmo Plus (with bar)



Colour: Silver (RAL 9006)  
Models: Cosmo and Cosmo Plus (with bar)



Colour: Graphite (RAL 7022)  
Models: Cosmo and Cosmo Plus (with bar)



Colour: White (RAL 9016)  
Models: Cosmo and Cosmo Plus (with bar)



Colour: Light Ivory (RAL 1015)  
Models: Cosmo and Cosmo Plus (with bar)



Colour: Claret (RAL 3004)  
Models: Cosmo and Cosmo Plus (with bar)



Colour: Blue (RAL 5013)  
Models: Cosmo and Cosmo Plus (with bar)