

# Boot washer Gentus 600



Model 600




Spray nozzles

**Boot washer Gentus 600** with water connection feeding the spray nozzles on the brushes with water. A separate hand brush gives the possibility to wash the boot leg.

Comes with a hand brush, four exchangeable brushes with spray nozzles, quick couplings and metal grate for coarse cleaning. Incoming water is connected with a 1/2" coupling. The waste water could be connected to a hose 40 mm Ø. Outlet optional on the side or backside.

### How to use Gentus 600

1. Place Gentus 600 on level ground.
2. Connect the onsite coldwater connection to the unit with a 1/2" coupling (not included).
3. Connect the hand-brush including water hose to the unit.
4. If needed, connect the wastewater to an onsite wastewater pipe.
5. Turn the onsite coldwater connection to "on".
6. Activate the hand-brush by turning the water valve.
7. Switch on the inlet valve for fresh water located on the side of the unit.
8. Spray nozzles are now active – washing procedure has started.
9. For stopping the washing procedure, turn "off" the coldwater connection.
10. ATTENTION when using below freezing: Danger of freezing! Risk of slipping in the area around the unit and the wastewater pipe.

<b>Gentus 600</b>	
	
<b>Height excl/incl handle (mm):</b>	<b>400/730</b>
<b>Width (mm):</b>	<b>730</b>
<b>Depth (mm):</b>	<b>400</b>
<b>Weight (kg)</b>	<b>ca 28</b>
<b>Material and colour</b>	<b>Stainless steel V2A</b>